

Aktiv H360R

Pro Series

Product Name: Aktiv H430R

Product Number: 700H360R

Description

Nice to know:
"aktiv" is the Danish word for "active"

Rechargeable headlamp with 33/360 lumens and red night light in front
Press the on/off 1. 33 lumens. 2. 360 lumens. 3. red night light 4. off
Press the on/off for 3 sec. to switch off

Specifications

Housing material	ABS
Lens material	Acrylic
On/off switch	Rubberised on/off which in the top
Battery type	1 x 102040 3,7V 850 mAh. Lithium rechargeable
LED	5W
Red LED	Yes - red night light in the front
Colour temperature (Kelvin)	7000
Colour rendering index (CRI)	>80
Output (lumens)	33 and 360 lumens
Run time (hours) down to 10% of full lumens	2.5 (high beam) / 12 (low beam)
Beam distance	34 m
Adjustable beam - zoom in and out	No
Max charging input	5V 1000 mAh
Charging time (hours)	2.5
Charging indicator	Red led
Battery level indicator	No
Charging port	Type-C USB
Cable for charger, 1 m (supplied in box)	USB-C into lamp, USB into charger
Interchangeable battery	No
Protection class	IK07 / IP65
Operating temperature range (Celcius)	-10-40
Headband	Silicone on the inside
Clips for helmet	Yes - supplied in the box
Declaration of conformity	CE and UKCA
Additional info	



General Information

Lamp weight (g)	57 g
Lamp dimensions (cm)	6,5 x 3,4 x 3
EAN code box (1 pc)	5703296703000
EAN code inner carton =	5703296703017
EAN code outer carton =	5703296703024
Harmonized standard code	8513100000

Packaging

Description	FSC cardboard. Gift box with Elwis PRO design
Box dimensions (cm)	W 12 x D 8,8 x H 8,5
Box weight (g)	165 g (including product 222 g)
Carton quantity (pcs)	inner carton 6 pc. / outer carton 48 pc.
Carton size (cm)	(inner carton) / (outer carton)
Carton weight (kg)	(inner carton) / (outer carton)

Features

Extreme low weight makes Aktiv H360R the best partner for all Activities.
Red night light in the front makes it very suitable for night adventures.
Work, Run, hunt, have fun - Aktiv H360R is your reliable partner.
Be active or in Danish "aktiv" (Aktiv H360R)

The following safety instructions apply
(Where relevant)

General Safety Instructions

Do not shine in eyes. Do not immerse in water or other liquids. Do not cover the lens when turned on and do not place the product with the lens/light source direct on a surface. Do not operate if the housing, wiring compartment or lens is open, missing, or damaged. Allow the product to cool down sufficiently before cleaning. Do not use cleaners that contain abrasives or solvents. Use on flat, stable surfaces. Do not operate with wet hands. Do not disassemble. Do not attempt to repair if damaged. Repairs must only be carried out by the manufacturer or authorized service representative. Clean with a dry clean cloth. Please note that lighting products generate heat – if the heat exceeds 60 degrees turn off the product.

Safety instructions - rechargeable products

Always inspect the charging plug - it must look dry, clean and undamaged. Only use the supplied charging cable and/or charger. Do not use a modified or damaged charger. Do not try to charge the product if it looks damaged. Do not turn on when charging. Do not leave on charge for over 24 hours. Do not charge below 0°C, above 40°C or at high humidity. Do not leave the product on charge near flammable material as it can cause a fire. Never charge without supervision. Always pay extremely attention to Li-ion batteries as they can explode. If not handled properly, the battery may cause explosion, leakage or fire. Do not expose batteries to direct sunlight. Do not disassemble or modify batteries. Do not apply strong impacts to the battery. Do not get batteries wet. Keep batteries out of reach of children and animals. Do not place batteries on top of an electromagnetic field. Do not use batteries that work for an extremely short period of time. Do not short-circuit the battery. Do not put a battery in a microwave oven, pressure container, or other such devices. Do not recharge batteries where heat can build up. If not handled properly, the battery may cause explosion, leakage, or fire.

Safety instructions - alkaline batteries

Only use new and undamaged batteries. Remove batteries from a device that is not being used for an extended period as they can leak. Never try to charge a non-rechargeable battery.



Elwis Lighting A/S, Sandtoften 11, 2820 Gentofte, DK
www.elwislighting.com - Tel. +45 70 20 10 24

Version 1 06/2022
© Elwis Lighting 2022
All details without obligation