

Blaze H380

Pro Series

Product Name: Blaze H380

Product Number: 600H380

Description

Rechargeable headlamp with 50/380 lumens and red safety light in the back
Press the on/off 1. 50 lumens. 2. 380 lumens. 3. Off
Press the on/off switch in the back to turn on red safety light. Press 2 times to activate blink. 3 times off

Specifications

Housing material	ABS & Aluminum
Lens material	Acrylic, optical
On/off switch	Rubberised on/off which in the top
Battery type	3 x AAA alkaline - included
LED	5W
Red LED	In the back
Colour temperature (Kelvin)	App. 7000
Colour rendering index (CRI)	>80
Output (lumens)	50 and 380 lumens
Run time (hours) down to 10% of full lumens	4 (high beam) / 19 (low beam)
Beam distance	260m
Adjustable beam - zoom in and out	Twist style optical focus system
Max charging input	N/A
Charging time (hours)	N/A
Charging indicator	N/A
Battery level indicator	N/A
Charging port	N/A
Cable for charger, 1 m (supplied in box)	N/A
Interchangeable battery	N/A
Protection class	IK07 / IP65
Operating temperature range (Celcius)	-10-40
Headband	Silicone on the inside
Clips for helmet	No
Declaration of conformity	CE and UKCA
Additional info	Can also use rechargeable battery Elwis SKU BAT011.



General Information

Lamp weight (g)	129g. (including batt. 164g.)
Lamp dimensions (cm)	6.7 x 5.1 x 4.1
EAN code box (1 pc)	5703296603508
EAN code inner carton =	5703296603515
EAN code outer carton =	5703296603522
Harmonized standard code	8513100000

Packaging

Description	FSC cardboard. Gift box with Elwis PRO design
Box dimensions (cm)	W 12,5 x D 11,5 x H 11
Box weight (g)	187g. (including product 351g.)
Carton quantity (pcs)	inner carton 6 pc. / outer carton 36 pc.
Carton size (cm)	(inner carton) / (outer carton)
Carton weight (kg)	(inner carton) / (outer carton)

Features

Reliable and heavy duty headlamp for the Runner as well as the DIY Handywoman/man.
Red light in the back for high-wis safety.
The headlamp features a great balance on the head with the battery compartment in the back.
Easy adjustable headband with silicone stripes for perfect fit.

The following Safety Instructions apply
(Where relevant)

General Safety Instructions

Do not shine in eyes. Do not immerse in water or other liquids. Do not cover the lens when turned on and do not place the product with the lens/light source direct on a surface. Do not operate if the housing, wiring compartment or lens is open, missing, or damaged. Allow the product to cool down sufficiently before cleaning. Do not use cleaners that contain abrasives or solvents. Use on flat, stable surfaces. Do not operate with wet hands. Do not disassemble. Do not attempt to repair if damaged. Repairs must only be carried out by the manufacturer or authorized service representative. Clean with a dry clean cloth. Please note that lighting products generate heat – if the heat exceeds 60 degrees turn off the product.

Safety Instructions - rechargeable products

Always inspect the charging plug - it must look dry, clean and undamaged. Only use the supplied charging cable and/or charger. Do not use a modified or damaged charger. Do not try to charge the product if it looks damaged. Do not turn on when charging. Do not leave on charge for over 24 hours. Do not charge below 0°C, above 40°C or at high humidity. Do not leave the product on charge near flammable material as it can cause a fire. Never charge without supervision. Always pay extremely attention to Li-ion batteries as they can explode. If not handled properly, the battery may cause explosion, leakage or fire. Do not expose batteries to direct sunlight. Do not disassemble or modify batteries. Do not apply strong impacts to the battery. Do not get batteries wet. Keep batteries out of reach of children and animals. Do not place batteries on top of an electromagnetic field. Do not use batteries that work for an extremely short period of time. Do not short-circuit the battery. Do not put a battery in a microwave oven, pressure container, or other such devices. Do not recharge batteries where heat can build up. If not handled properly, the battery may cause explosion, leakage, or fire.

Safety instructions - alkaline batteries

Only use new and undamaged batteries. Remove batteries from a device that is not being used for an extended period as they can leak. Never try to charge a non-rechargeable battery.



Elwis Lighting A/S, Sandtoften 11, 2820 Gentofte, DK
www.elwislighting.com - Tel. +45 70 20 10 24

Version 1 06/2022
© Elwis Lighting 2022
All details without obligation