

BFF S360R

Pro Series

Product Name: BFF S360R

Product Number: 700S360R

Description

BFF S360R is simply your Best Friend Forever. Trustable and powerful with 360 lumens. Rechargeable flashlight with 63 & 360 lumens
On/off 1. 63 lumens 2. off 3. 360 lumens 4. off
Hold head and turn tube for access to charging port behind the rubber sealing.

Specifications

Housing material	Aluminum
Lens material	Acrylic, optical
On/off switch	Bottom, red rubber
Battery type	ICR 14500 Li-Ion 3.7V 750mAh (may also use 1xAA alkaline battery)
LED	5W
Red LED	No
Colour temperature (Kelvin)	7000
Colour rendering index (CRI)	>80
Output (lumens)	63 and 360 lumens
Run time (hours) down to 10% of full lumens	3 / 6
Beam distance	240 m
Adjustable beam - zoom in and out	Sliding style optical focus system
Max charging input	5V 2000mAh
Charging time (hours)	4
Charging indicator	Yes - red led
Battery level indicator	No
Charging port	Type C USB charging port
Cable for charger, 1 m (supplied in box)	USB C into lamp and USB into adapter
Interchangeable battery	Yes
Protection class	IK07 / IP65
Operating temperature range (Celcius)	-10-40
Declaration of conformity	CE & UKCA
Additional info	Pocket clip and lanyard included in box BFF can also use 1 x AA alkaline battery



General Information

Lamp weight (g)	93g incl rechargeable batt.
Lamp dimensions (cm)	3 x12 cm
EAN code box (1 pc)	5703296703604
EAN code inner carton =	5703296703611
EAN code outer carton =	5703296703284
Harmonized standard code	8513100000

Packaging

Description	FSC cardboard. Gift box with Elwis PRO design
Box dimensions (cm)	W 16.2 x D 7.97 x H 6.16
Box weight (g)	161 g. (including product 254g)
Carton quantity (pcs)	innerbox 6pc. / outerbox 48 pc.
Carton size (cm)	25.3x17.2x13.6 / 52.9x36.2x29.7
Carton weight (kg)	14kg

Features

BFF S360R is simply your Best Friend Forever. Trustable and powerful with 360 lumens. Lightweight torch with sliding focus makes it perfect for almost all purposes.
Can also use 1 x AA battery (not included in box).
Supplied with pocket clip, lanyard and cable for charger.

The following Safety Instructions apply (Where relevant)

General Safety Instructions

Do not shine in eyes. Do not immerse in water or other liquids. Do not cover the lens when turned on and do not place the product with the lens/light source direct on a surface. Do not operate if the housing, wiring compartment or lens is open, missing, or damaged. Allow the product to cool down sufficiently before cleaning. Do not use cleaners that contain abrasives or solvents. Use on flat, stable surfaces. Do not operate with wet hands. Do not disassemble. Do not attempt to repair if damaged. Repairs must only be carried out by the manufacturer or authorized service representative. Clean with a dry clean cloth. Please note that lighting products generate heat – if the heat exceeds 60 degrees turn off the product.

Safety Instructions - rechargeable products

Always inspect the charging plug - it must look dry, clean and undamaged. Only use the supplied charging cable and/or charger. Do not use a modified or damaged charger. Do not try to charge the product if it looks damaged. Do not turn on when charging. Do not leave on charge for over 24 hours. Do not charge below 0°C, above 40°C or at high humidity. Do not leave the product on charge near flammable material as it can cause a fire. Never charge without supervision. Always pay extremely attention to Li-ion batteries as they can explode. If not handled properly, the battery may cause explosion, leakage or fire. Do not expose batteries to direct sunlight. Do not disassemble or modify batteries. Do not apply strong impacts to the battery. Do not get batteries wet. Keep batteries out of reach of children and animals. Do not place batteries on top of an electromagnetic field. Do not use batteries that work for an extremely short period of time. Do not short-circuit the battery. Do not put a battery in a microwave oven, pressure container, or other such devices. Do not recharge batteries where heat can build up. If not handled properly, the battery may cause explosion, leakage, or fire.

Safety instructions - alkaline batteries

Only use new and undamaged batteries. Remove batteries from a device that is not being used for an extended period as they can leak. Never try to charge a non-rechargeable battery.



Elwis Lighting A/S, Sandtoften 11, 2820 Gentofte, DK
www.elwislighting.com - Tel. +45 70 20 10 24

Version 1 06/2022
© Elwis Lighting 2022
All details without obligation